



IRiS Soundboard

Instruction Manual

For optimal results, please read and follow
instructions carefully
Please keep for future reference

 **WARNING:**
CHOKING HAZARD – Small Parts
Not suitable for children under 3 years.



experia
innovation in every sense

Congratulations on the purchase of your IRiS Soundboard!

The Soundboard has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of learning and fun!

The Soundboard offers endless opportunities to develop cause and effect, speech and language skills and many more.

Please ensure you read and follow these Instructions carefully before installing or operating the unit. Please keep this manual for future reference.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

-) 18 hours of recording time
-) 8 groups of pre-recorded sounds
-) 2 groups of user recorded sounds
-) 80 sounds available in total
-) Easy to use
-) 2 Year Manufacturers Guarantee (Collect and Return)

Pack contents

- 1 x Soundboard
- 1 x Power Supply

Sound Groups

- 0 - User recorded sounds
- 1 - User recorded sounds
- 2 - Domestic Animals
- 3 - Household Sounds
- 4 - Numbers One to Eight
- 5 - Favorite Colour - English
- 6 - Favorite Colour - Spanish
- 7 - Transport
- 8 - Circus
- 9 - Nursery Rhymes

Controls



Volume – controls the playback volume

Pair Button – No Function on this product

Sound No – Sound Group number

Sound Select – press to select Sound Groups

Microphone – for recording into

Record Button – press to enter Record Mode

Getting Started

1. Switch on the unit via the mains after plugging in the power supply.
2. Choose the group of sounds you'd like to hear by pressing the Sound Select button.
3. Now it's ready to use, activate one of the buttons and the speaker responds.

Pairing to IRiS Talkers

1. Turn the unit on.
2. Press the "Pair" button – the display flashes "P" to indicate Pairing Mode for 60 seconds.
3. Activate any IRiS talker within 60 seconds and the IRiS Speaker display will stop flashing "P" and return to the previous displayed Sound Group number. Pairing is now complete.
4. If it does not respond repeat steps 1 – 3.
5. If it continues to be unresponsive try changing the batteries in the IRiS Talker or pair to a different device.

Using the "snap frame" windows

The windows illuminate when the button immediately below is pressed. The snap frames allow A4 pictures to be held in place while the window is illuminated and a sound reward played.

Recording your own Sounds

After switching the unit on and pairing to an IRiS Talker, please follow the instructions below to record a message onto the Recordable Speaker. Messages can be recorded over again and again. This is only relevant to Sound Groups 0 and 1. In this example we have paired the Soundboard to the IRiS Qube

1. Decide which window position on the Soundboard you want to record your message / sound to.
2. Select Sound Group 0 or 1 and Press the "Record" button – the display flashes "r" to indicate Recording Mode for a few minutes until you continue the next step.
3. Activate the button below the window.
4. The unit will now begin recording – make the sound you want to record. Once the sound has been recorded activate the button below the window once again to stop the recording. This may take a little practice to get right.

5. Activate the button below the window you have just recorded to so you can listen to the sound you have just recorded.
6. Continue to record onto the other window positions by repeating the above.

Please note a single bar is displayed if no sound is available for playback.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable. You must ensure the unit is not dropped, thrown, stood upon, immersed in water, etc.

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so,

A2. Have you checked the volume control, if so

A3. Have you checked though all the sound groups, if so

Please contact us.

Contact Details

For USA please email support@experia-usa.com

For Canada please email support@experia-canada.com

For UK and rest of the world email support@experia-innovations.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: ideas@experia-innovations.co.uk.

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia, Lydia Pinkham House, 3 Spring Hill Road, Park Springs, Barnsley, South Yorkshire, S72 7BQ.





© Copyright 2010-2011 Experia All rights reserved. Experia is a registered trademark.